



RAS-3G

**UMTS GPRS EDGE
IP Router - RAS - firewall**

USER GUIDE

Document reference : 9020009-01

The RAS-3G router is manufactured by

ETIC TELECOM

**13 Chemin du vieux chêne
38240 MEYLAN
FRANCE**

TEL : + 33 4-76-04-20-05

FAX : + 33 4-76-04-20-01

E-mail : hotline@etictelecom.com

web : HUUwww.etictelecom.com

PRESENTATION

1	SECURITY RECOMMENDATIONS	7
2	CERTIFICATE OF CONFORMITY	8
3	PRODUCTS IDENTIFICATION	9
4	DATA-SHEET	11
5	PRODUCT OVERVIEW	13
5.1	Functions overview	13
5.2	Main features	15

INSTALLATION

1	DIMENSIONS	17
2	CONNECTORS	17
3	LED INDICATORS	20
4	DIP SWITCHES	21
5	FACTORY DEFAULT PUSH-BUTTON.....	21
6	MOUNTING THE PRODUCT ON A DIN RAIL OR REMOVING IT	21
7	COOLING	22
8	RS232 INTERFACE	22
9	RS485 INTERFACE	23
10	DIGITAL INPUT AND OUTPUT	23
11	CONNECTING THE ANTENNA.....	23
12	INSTALLING THE SIM CARD	24

SET UP

1	SET UP STEPS	25
2	CONNECTING A PC TO THE ROUTER FOR CONFIGURATION.....	26
2.1	Overview.....	26
2.2	First configuration.....	26
2.3	Modifying the configuration from the LAN	27
2.4	Modifying the configuration remotely	28
3	REBOOTING THE ROUTER AFTER PARAMETERS CHANGES.....	28
4	RECOVERING THE FACTORY LAN IP ADDRESS.....	28
5	RECOVERING THE FACTORY CONFIGURATION.....	28

../..

... SET UP

6	RESTRICTING ACCESS TO THE ADMINISTRATION SERVER	29
7	RECOVERING A FREE ACCESS TO THE ADMINISTRATION SERVER	29
8	FACTORY CONFIGURATION	29
9	LAN INTERFACE SET UP	30
9.1	IP protocol	31
9.2	DHCP server	31
10	UMTS – GSM-GPRS-3GDGE INTERFACE SET UP	32
10.1	Modem menu	32
10.2	Connection menu	32
10.3	“Control” menu	33
11	SETTING A CONNECTION TOWARDS THE RAS-3G USING THE DYNDNS SERVICE	34
12	CREATING VPN CONNECTIONS BETWEEN ROUTERS	35
12.1	Principles	35
12.2	IPSec VPN connections	37
12.3	TLS VPN connections	43
13	ROUTING FUNCTIONS	47
13.1	Basic routing function	47
13.2	Static routes	48
13.3	RIP protocol	49
14	ADDRESS AND PORT TRANSLATION	50
14.1	Port forwarding	50
14.2	Advanced network address and port translation	51
15	VRRP REDUNDANCY	55
15.1	Principle	55
15.2	Configuring VRRP on the LAN interface	55
15.3	Configuring VRRP on the WAN interface	56
16	REMOTE USERS CONNECTIONS SERVICE	57
17	REMOTE USERS CONNECTIONS	58
17.1	Principles	58
17.2	Configuring a TLS connection	59
17.3	Configuring a PPTP connection	61

../..

... SET UP

18	M2ME_CONNECT SERVICE	62
18.1	Overview.....	62
18.2	Configuring a M2Me_Connect connection	63
19	USERS LIST	64
20	FIREWALL	66
20.1	Overview.....	66
20.2	Main filter.....	67
20.3	Remote users filters	69
21	SERIAL TO IP GATEWAY	73
21.1	Modbus menu	74
21.2	RAW TCP gateway.....	76
21.3	RAW UDP gateway	78
22	USB TO IP GATEWAY.....	79
22.1	Principles	79
22.2	Configuration	79
23	ADVANCED FUNCTIONS.....	80
23.1	Adding a certificate	80
23.2	Alarms	80
23.3	Configuring the web portal.....	81
23.4	Configuring the DNS server	82

DIAGNOSTIC & MAINTENANCE

1	DIAGNOSTIC MENU.....	83
2	SAVING THE CONFIGURATION TO A FILE	85
3	UPDATING THE FIRMWARE	86

Appendix 1 : [Management web server description](#)

1 Security recommendations

The RAS-3G is a low power radio transmission and reception device. It conforms to rules imposed to UMTS or GSM-GPRS-EDGE terminals.

Check that using such a device is authorized at the location where you wish to install the router.

Do not use the RAS-3G router in locations with a potentially explosive atmosphere like, for instance, petrol stations or areas where the atmosphere contains chemicals or particles.

The RAS-3G uses the UMTS radio network and wireless waves. It is why, it is not possible to guarantee it will connect without interruption.

It is not possible to rely only the RAS-3G and the UMTS network to guarantee the security of an automated system.

2 CERTIFICATE OF CONFORMITY

The manufacturer, ETIC Telecom – 13 chemin du vieux chêne – 38240 Meylan – France, Hereby declares that the listed products

Type of device : UMTS & GSM - GPRS – EDGE router

Models: RAS-3G router family

conforms to the Council Directive 1999/5/EC related to radio and telecommunication terminal equipments.

The harmonized standards to which the equipment complies are :

Standard	Title
EN301489-1	Electromagnetic compatibility and Radio spectrum Matters : Part 1 : General requirements
EN301489-7	Electromagnetic compatibility and Radio spectrum Matters : Part 7 : Specific conditions for mobile and portable radio and ancillary equipment of digital cellular radio
EN61000-6-2 Ed. 2001	Immunity : EN60100-4-2 Electrostatic Discharge EN60100-4-3 Radiated Immunity EN60100-4-4 EFT/Burst Immunity EN60100-4-5 Surge Immunity EN60100-4-6 Conducted Immunity
EN61000-6-4 Ed 2001	Emission : EN55022 radiated and conducted emission
EN60950	Security
EN50385	Human exposure to radio frequency fields exposure
EN301511	Global System for mobile communication

Gilles Bénas
Quality manager
5th december 2011

3 Products identification

RAS-3G	-1400	-1201	-1220	1230
Frequency band UMTS	850 1900 / 2100 MHz			
Frequency band GSM GPRS	850 / 900 / 1800 / 1900 MHz			
IP router	•	•	•	•
Remote access server PPTP or TLS - 25 users	•	•	•	•
Firewall SPI	•	•	•	•
Serial gateway	-	-	•	•
USB gateway	-	•	-	-
25 IPSEC or SSL client or server VPNs	•	•	•	•
RJ45 10/100 BT	4	2	2	2
RS232	-	-	1	2
RS485	-	-	1	-
USB host	-	1	-	-
Port forwarding	•	•	•	•
Source IP address translation (NAT)	•	•	•	•
SNMP	•	•	•	•
DHCP client or server over the LAN interface	•	•	•	•
DHCP client 3G interface	•	•	•	•
RIP LAN & WAN	•	•	•	•
Digital input for emails	1	1	1	1
Html Configuration	•	•	•	•
IO Viewer compatible	•	•	•	•
VRRP	•	•	•	•
Masquerading	•	•	•	•
M2Me_Connect	•	•	•	•

4 Data-sheet

General characteristics	
Dimensions	137 x 48 x 116 mm (h, l, p)
Electrical safety	EN 60950- UL 1950
EMC	ESD : EN61000-4-2 : Discharge 6 KV RF field : EN61000-4-3 : 10V/m < 2 GHz Fast transient : EN61000-4-4 Surge voltage : EN61000-4-5 : 4KV line / earth
RoHS	2002/95/CE (RoHS)
Supply voltage	RAS-3G-1220 : 10 to 30 VDC - 125 mA / 24 VDC RAS-3G-1201 : 10 to 60 VDC - 125 mA / 24 VDC RAS-3G-1230 : 10 to 60 VDC - 125 mA / 24 VDC RAS-3G-1400 : 10 to 60 VDC - 210mA / 24 VDC
Operating T°	-20°C / + 60°C Humidity 5 – 95 %

Air Interface	
	RAS-3G
Frequency UMTS	850 / 1900 / 2100 MHz
Frequency GSM	850/ 900 / 1800 / 1900 MHz
RF power	EGSM850 EGSM900 : class 4 (2 W) GSM1800 GSM1900 : class 1 ((1 W)
Antenna	Connector SMA
UMTS HSDPA	HSDPA 7,2 Mb/s downlink / 384 kbps uplink
EDGE-GPRS	236,8 Kb/s downlink & uplink
GPRS	Multislot class 12

Ethernet / IP router	
Ethernet	10/100 BT – 2 or 4 switched ports
IP router	Remote connections - static routes – RIP V2
IP address translation	Source IP @ translation (NAT) Destination IP @ translation (DNAT) Port translation (Port forwarding)
DNS	Domain name
IP address assignment	Fixed IP @ or DHCP client or DHCP server

Security	
VPN	Client or server IPSEC or TLS/SSL Encryption 3DES Certificate X509 or preshared key 25 VPNs maximum of the same type (TLS or IPsec)
Firewall	Stateful packet inspection (50 rules)
Logs	Date and time stamped logs

Remote access server (RAS)	
User list	25 users
Connection	VPN PPTP / L2TP-IPSec / TLS Open VPN Login & password Certificate X509
M2Me (*)	VPN Compliant with the M2Me_Secure VPN client Compliant with the M2Me_Connect mediation service
Alarms	3 inputs : emails

Serial interface (*)	
RS232	1200 – 115200 kb/s parity N / E / O RS232 or RS485 (2 wires)
USB	USB host interface
Serial asynchronous to IP gateways	Modbus master and slave Raw TCP client and server Telnet RAW UDP "multicast" unitelway

*option

5 Product overview

5.1 Functions overview


The RAS- 3G router is designed to interconnect safely automated devices over the UMTS 3G or the GPRS-EDGE service

The connection can be set with devices connected to the Internet or with devices connected to a private IP network or between RAS-3G routers.

VPN can be set between routers to provide safe and full communication between the devices connected to the routers.

The product includes an up-to-date serial to IP gateway, enabling to connect devices directly to the 3G network and the Internet.


The RAS-3G is at the same time an IP router, a VPN client or a VPN server, a remote access server (RAS) and a stateful packet inspection firewall.



The RAS-3G is a member of the range of industrial routers manufactured by ETIC TELECOM ; that family includes :


- an ADSL router
- an Intranet router (Ethernet interfaces)
- an up to 256 VPNs server rack
- a PSTN router
- an ISDN router
- a PPP RS232 router for particular uses.

That range makes possible to build state-of-the-art remote control systems.



Due to its functions and its worldwide 3G module, the RAS-3G provides to authorized users a remote access to remote industrial devices or industrial networks around the world through the 3G or GSM-GPRS network.

If the IP address assigned to the RAS-3G router by the wireless service provider is not fixed, It is possible to use either the DynDNS service, or the M2Me_Connect service provided by ETIC TELECOM.




The M2Me_Connect service makes possible to set a secure connection between

- A remote maintenance PC on one hand,
- and an Ethernet or a serial Machine network on the other hand through the Internet.

The M2Me_Connect service is specially efficient for remote maintenance of automated systems.

The M2Me_Connect service makes that connection possible and easy even if the IP addresses of the PC on one hand and of the Machine network on the other hand are private and or dynamic.



5.2 Main features

The RAS-3G router provides the functions hereafter.

Remark : Some features are provided only on particular models.

IP router

The RAS-3G firewall-router provides powerful, flexible and comprehensive solutions to route IP packets between the LAN and the 3G interface.

VPNs client or server

The RAS-3G router is able to establish safe VPN tunnels.

Once a VPN is established between two RAS-3G routers, each IP device connected to the first RAS-3G can exchange IP packets with any device connected to the other RAS-3G.

The VPN mechanism ensures at the same time end-points authentication, data integrity and confidentiality.

The RAS-3G router is able to establish up to 25 IPSec or TLS – SSL VPNs.

Authentication can be carried-out with a pre-shared key or with a certificate.

SPI Firewall

The RAS-3G incorporates a stateful inspection firewall.

It is able to check source and destination IP addresses and port numbers for data coming from the WAN interface or from the LAN interface.

Remote access server

Remote users are authenticated, an IP address belonging to the LAN interface is automatically assigned to their PC.

Moreover, The traffic coming from the PC of each remote user is filtered according to the remote user identity.

M2Me_Connect service TM *

The RAS-3G is compliant with M2Me_Connect, the remote connection service provided by ETIC TELECOM over the Internet.

Serial gateway *

The product includes an asynchronous (RS232-RS485) to IP gateway, enabling to connect asynchronous or USB devices directly and safely to the Ethernet network.

DHCP client or server

DHCP is a standard Internet protocol that enables a DHCP server to dynamically distribute IP addresses and configuration information to the DHCP clients.

The RAS-3G can be a DHCP client or server on its LAN interface or a DHCP client on its 3G (WAN) interface.

Emails – sms

An email (or SMS) can be sent each time one of the two digital inputs is opened or closed.

SNMP

The RAS-3G router is an SNMP agent.

Html and DIP switches configuration

The RAS-3G is configured with a web server .

Two DIP switches allow to assign an IP address to the RAS-3G over the LAN interface : DHCP client or server, factory IP address or stored IP address.

EticFinder™ software

The ETICFinder software is delivered with the product.

It detects the ETIC products connected to an Ethernet interface and displays the MAC address and the IP address of each product.


M2Me_Secure™ VPN client software

M2Me_Secure is a TLS client able to register up to 100 VPN connections the user can set on a click.

* That feature is provided only on particular models; see the [Product Identification table](#) above.

1 Dimensions

Dimensions



2 Connectors

RAS-3G-1220

Protection lid :
DIP-switches
Factory default push-button

SMA Antenna Connector

LAN
2 X 10/100 BT

RS485

RS232

8 pos. screw block :
1 digital input
1 digital output
10 to 30 VDC supply V.



RAS-3G-1230

Protection lid :
DIP-switches
Factory default push-button


SMA Antenna Connector

LAN
2 X 10/100 BT

RS232-1

RS232-2

8 pos. screw block :
1 digital input
1 digital output
10 to 30 VDC supply V.




RAS-3G-1400

Protection lid :
DIP-switches
Factory default push-button

SMA Antenna Connector

LAN
4 X 10/100 BT

8 pos. screw block :
1 digital input
1 digital output
10 to 60 VDC supply V.



8 positions screw terminal : Supply voltage and digital input / output		
Position	Name	Description
1	Power 1 +	RAS-3G-1220 : 10 to 30 VDC All other models : 10 to 60 VDC
2	Power 1 -	GND
3	Power 2 +	RAS-3G-1220 : 10 to 30 VDC All other models : 10 to 60 VDC
4	Power 2 -	GND
5	3V3	3 V DC provided by the RAS router
6	In	Digital input
7	F +	Digital output + (max 50Vdc - 0,6A)
8	F -	Digital output -




RJ45 connector : Ethernet		
Position	Name	Description
1	Tx +	Emission polarity +
2	Tx -	Emission polarity -
3	Rx +	Reception polarity +
4	N.C	-
5	N.C	-
6	Rx -	Reception polarity -
7	N.C.	-
8	N.C.	-


RS485 screw terminal		
Position	Name	Description
1	A	RS485 polarity A
2	B	RS485 polarity B

RS232 RJ45 connector port 1 (To connect to a DCE to the RS232 port)			
Position	Circuit		Function
1	DTR - 108	OUT	Data terminal ready
2	TD - 103	OUT	Data Emission
3	RD - 104	IN	Data Reception
4	DSR - 107	IN	Data set ready
5	SG - 102	-	Ground
6	Not used	OUT	-
7	CTS - 106	IN	Clear to send
8	RTS - 105	OUT	Request to send

RS232 RJ45 connector port 2 (To connect to a DCE to the RS232 port)			
Position	Circuit		Function
1			Not used
2	TD - 103	OUT	Data Emission
3	RD - 104	IN	Data Reception
4			Not used
5	SG - 102	-	Ground
6			Not used
7			Not used
8			Not used

3 Led indicators

Indicator	Status	Description
All models		
Line / 	Flashing green until connection to the 3G network	After power-on, and during 30 seconds, the reception signal strength is indicated by the number of flashes. <u>See the table below.</u> Remark : The diagnostic menu reports the value (dBm) of the reception signal.
	Green	Then , when the router is connected to the 3G network, this led is lit.
	Green	The supply voltage is present
	Green	The unit is ready
	Red	The product is starting The SIM card is not present The hardware is in failure
RAS-3G-1220 (with 1 RS232 and 1 RS485 interface)		
Rx	Flashing green	Bytes received from the RS232 or RS485 (to RAS)
Tx	Flashing green	Bytes transmitted to the RS22 or RS485 (from RAS)
RAS-3G-1230 (with 2 RS232 interfaces)		
Rx	Flashing green	Bytes received from the RS232 –1 interface (to RAS)
Tx	Flashing green	Bytes transmitted to the RS22 –1 interface (from RAS)
Rx	Flashing green	Bytes received from the RS232 –2 interface (to RAS)
Tx	Flashing green	Bytes transmitted to the RS22 –2 interface (from RAS)

 RF reception signal strength indicator		
Description	Status	RF Reception dBm (Diagnostic menu)
3 flashes	<u>Good reception</u>	-50 to - 80
2 flashes	<u>Sufficient reception</u> The level of the reception signal is sufficient to set a connection. However, some error may occur which might decrease the data rate.	-81 to –90
1 flash	<u>Insufficient reception</u> The level of the reception signal is weak ; errors and disconnection might occur. The reception conditions must be improved to get a reliable connection	-91 to -110
Always OFF	<u>No reception</u> Control or replace the antenna or the product itself. Can a communication be set with a mobile phone ?	< -111
Always ON	The router is now connected to the 3G-GSM network	

4 DIP switches

DIP switches		
SW 1	SW 2	Management
OFF	OFF	The current IP@ of the product is the stored IP @
ON	OFF	The active IP@ of the product is the factory IP@ : 192.168.0.128 No login and password are required to access to the html server
OFF	ON	The active IP@ is provided by the BOOTP or DHCP server.
ON	ON	Reserved
SW 3, SW 4		Not used

5 Factory default push-button

A push-button is located under the lid at the top of the product.

It enables to restore the factory profile.


- To restore the factory profile, switch the power on while pressing the push-button until the RUN light turns green.

Attention : Once the factory profile has been restored, the stored configuration is lost.


6 Mounting the product on a DIN rail or removing it

Mounting the unit on the DIN rail

This unit should be mounted on 35 mm DIN-rail, horizontally mounted.



Removing the unit from the DIN rail



7 Cooling

To avoid obstructing the airflow around the unit, the spacing must be at least 25 mm above and below, and 10 mm left and right.

8 RS232 interface

The RS232 data rate can be set from 1200 to 115200 b/s with parity (even / odd) or no parity.

The data terminal must be less than 10 meters far from the modem.

Cables can be provided to connect the product to DTE and DCE as follows :

RS232 cables (L=1m)		
Code	User connector	Cable function
CAB592	SubD 9 male	To connect a DCE to the RAS-3G
CAB593	SubD 9 female	To connect a DTE to the RAS-3G
CAB609	Wires	To connect a device providing a specific connector

CAB593 cable - DB9 female RS232 connector				
Position	Circuit		Name	RAS - Terminal
1	CD	109	Carrier detect	⇒
2	RD	104	Data Reception	⇒
3	TD	103	Data Emission	⇐
4	DTR	108	Data terminal ready	⇐
5	GND	102	Ground	
6	DSR	107	Data set ready	⇒
7	RTS	105	Request to send	⇐
8	CTS	106	Clear to send	⇒
9	RI	125	Ring indicator	⇒


CAB592 cable - DB9 male RS232 connector				
Position	Circuit		Name	RAS - Terminal
1	CD	109		⇐
2	RD	104	Data Reception	⇐
3	TD	103	Data Emission	⇒
4	DTR	108	Data terminal ready	⇒
5	GND	102	Ground	
6	DSR	107	Data set ready	⇐
7	RTS	105	Request to send	⇒
8	CTS	106	Clear to send	⇐
9	RI	125	Ring indicator	⇐

9 RS485 interface

The RS485 serial interface is provided on the front panel 2 pins screw-block.

Polarisation resistors

1 Kohm bus polarisation resistors are included inside the product.



RS485 line adaptation

For a several meters long connection over the RS485 local interface, it is not necessary to adapt the RS485 line. For a longer distance, connect a 120 Ohm resistor at each end of the line.

10 Digital input and output


Digital output :

Max. voltage : 48 VDC

Max. current : 500 mA

Digital input :

Maximum voltage : 20 VDC




11 Connecting the antenna


If the cabinet in which the router has to be installed is made of metal, the antenna has to be installed outside the cabinet; for instance on its top.

The antenna must be ordered separately; the models below are available :

- 90 ° antenna (ANT210).
- Magnet mount antenna (ANT211)
- Roof antenna (ANT212)



ANT211



ANT212 (1,50 m)




12 Installing the SIM card

Before installing the SIM card into the router, its PIN code must have been cleared. The PIN code can be cleared using a usual telephone or a smart phone.

Step 1 : Install the SIM card

- Power off the router.
- Remove the anti-steal lid at the top of the product
- Press the SIM card eject button and remove the SIM card drawer.
- Insert the SIM card into the SIM card drawer.
- Slide the drawer back into the unit and make sure it locks into place.

Step 2 : Check the reception signal strength

- Switch-on the router
- The  led first lights red and then green.
- The  power indicator lights green.
- The  reception led flashes to indicate cyclically the reception signal strength.

The reception led must flash at least 2 times to ensure a reliable connection.

If the reception led flashes only one time, the reception is poor ; it must be improved otherwise the connection will be probably not reliable.

If the reception led remains OFF, it means that the 3G service cannot be received at that location or that the antenna is not correctly connected or is damaged.

- If the  led lights red, it signifies that the PIN code of the SIM card has not been cleared.

1 Set up steps

To configure the router, we advise to proceed as follows :

- [Connecting a PC to the router](#)
- [Setting up the LAN interface](#)
- [Setting up the WAN interface](#)
- [Setting up the DynDNS service](#)
- [Setting up VPNs](#)
- [Setting up routing and IP address translation functions](#)
- [Setting up address translation and port forwarding](#)
- [Setting up remote users connections and the M2Me Connect service](#)
- [Setting up the remote users list](#)
- [Setting up the serial gateway or the USB gateway](#)
- [Setting up the firewall](#)

The RAS-3G router is configured with a PC and an HTML browser.

2 DIP switches enable you to set the IP address : Factory address, stored address, BootP or DHCP client or server.

For the first configuration, we advise to connect the PC directly to the router Ethernet interface.

Modifications can be carried out through the LAN or remotely.

2 Connecting a PC to the router for configuration

2.1 Overview

Administration server address :

The administration html server is located at the LAN IP address of the router. The default factory address is 192.168.0.128.

First setup :

For the first configuration, we advise to connect the PC directly to the LAN interface of the RAS-3G router.

Setup modifications from the LAN or remotely :

Modifications can be carried out
from the LAN interface,
or from the Internet using a port forwarding rule (not advised for security reasons),
or using a remote user connection PPTP, TLS, L2TP/IPSec,
or through a VPN.

Restoring the factory IP address :

The factory IP address of the router on the LAN interface can be restored by setting the DIP switches SW01 ON and SW02 OFF.

In that position of the DIP switches, the stored configuration is not deleted.

Setting the DIP switches in that position gives also a free access to the administration server from the LAN interface.

During operations, the DIP switches must not be left in that position.

Network IP address :

Later in the text, we often speak of "network address".

We mean the lowest value of the addresses of the network.

For instance, if the netmask of a network is 255.255.255.0, the network address of that network is X.Y.Z.0.

Copy and paste :

Parameters must be entered with the keyboard; they cannot be pasted.

However, it can be useful to paste a string when it is long to avoid errors.

In that case, paste the string, delete the last character of the pasted string, and enter it again with the keyboard.

Saving and restoring the parameters file (see the maintenance chapter)

A parameters file can only be downloaded to a product having the same firmware version. It is why, we advise to assign a name to a parameter file including the product name and the software version like for instance "myrouterfile_ras3g1220_V241.bin".

2.2 First configuration

Step 1 : Check the DIP switches

Coming from factory, the DIP switches SW1 and SW2 are set OFF to select the stored IP address.

Coming from factory, the stored IP address is the factory IP address 192.168.0.128.

Step 2 : Create or modify the PC IP connection.

Assign to the PC an IP @ in accordance with the RAS-3G IP address.


For the first configuration, assign or instance 192.168.0.127 to the PC.

Step 3 : Connect the PC directly to the LAN interface of the RAS-3G router using any Ethernet cable (straight or cross wired).

Step 4 : Launch the navigator

Enter the LAN IP @ of the router 192.168.0.128.

The Home page of the administration server is displayed



2.3 Modifying the configuration from the LAN

- **If the IP @ of the RAS-3G on the LAN interface is fixed**

Step 1 : Ensure the DIP switch SW1 and SW2 are OFF to select the stored IP @.

Step 2 : Launch the html browser and enter the IP address assigned to the router.

Or, launch the ETICFINDER utility to detect the RAS-3G address.

Remark :

If the home page cannot be displayed, refer [below](#).

- **If the IP @ of the RAS-3G on the LAN interface is assigned by a DHCP server**

Step 1 : Ensure the DIP switch SW1 is OFF and SW2 ON to select DHCP client operation.

Step 2 : Launch ETIC FINDER to detect the RAS-3G address over the LAN interface.

Click the product once detected.

The Home page of the administration server is displayed.

Remark :

If the home page cannot be displayed, refer [below](#).

2.4 Modifying the configuration remotely

Coming from the factory, the firewall rejects all the IP frames coming from the 3G network.

To modify remotely the configuration, one can use one of the methods described hereafter :

Set a [remote user PPTP, TLS, L2TP/IPSec connection](#) towards the antenna IP address of the RAS-3G router.

Connect a PC to the RAS-3G through a [VPN](#) set between the RAS-3G t and another router.

Set up a [port forwarding](#) rule to authorise IP frames transmitted to the antenna IP address to be forwarded to the LAN IP address of the RAS-3G router.

If the IP is public but dynamic, one can use the DynDNS service.

In any case, one can use the professional M2Me_Connect service.

3 Rebooting the router after parameters changes

- After the parameters of any page have been completed, click the « Save » button at the bottom of the page.
- After some parameters changes, the RAS-3G must restart.
When the configuration has been completely carried out, click the « **Reboot** » red button in the green bar, when displayed.
- Once the product has restarted, check the « **Reboot** » button has disappeared from the green bar.

To save the configuration file to a hard disk :

- Select the “maintenance” menu and then the “Save / restore” menu.
- Click the “Save current configuration to disk” button.

4 Recovering the factory LAN IP address

When launching the html browser, the homepage of the html server may not be displayed; the cause may be the IP address you entered was wrong.

if the IP address you enter is wrong, you can recover the factory IP address by setting SW01 ON and SW2 OFF but the configuration of the router is not lost.

The factory IP address 192.168.0.128 will be restored as long as the SW01 and SW02 micro switch will be left in that position.

Remark : The SW01 and SW02 must not be left in that position during operations.

5 Recovering the factory configuration

If firewall rules have been created finally preventing from reaching any IP address on the LAN interface including the router itself, it may be necessary to restore the factory configuration of the router.

To restore the RAS-3G factory configuration,

- Switch OFF the power supply of RAS-3G router.
- Press the push button located on the top part of the RAS-3G router under the lid and, switch-on the power supply.
- Keep the push button pressed until the operation led turns red.

Remark : The stored configuration will be lost; the factory IP address 192.168.0.128 will be restored.

6 Restricting access to the administration server

When the RAS-3G comes from factory, the html server is not protected by a password. It is advised to protect the access to the administration server with a login and a password.

To protect access to the administration server,

- Select the “Setup” menu, the “Security” menu and then the “Administration menu”.

Remark : For more simplicity, we advise to chose the login and the password of one of the remote users stored in the user list.

7 Recovering a free access to the administration server

If the Login & or password entered to reach the administration server have been rejected, it is possible to recover a free access to the administration server from the LAN only, by setting SW01 ON and SW2 OFF.

Remark :

The factory IP address 192.168.0.128 will also automatically be restored as long as SW01 will remain ON and SW2 OFF.

During normal operations SW01 and SW02 must not be left in that position.

8 Factory configuration

Coming from factory, the router configuration is as follows :

LAN IP @	192.168.0.128
WAN IP @	None
Default user :	Login = admin ; Password = admin
Admin. Web server restriction :	None

Firewall :

Remote user filters	Authorises any remote users belonging to the user list to reach a LAN IP address using a PPTP or TLS connection
Main filter	IP frames coming from the WAN interface to the LAN are dropped IP frames transported inside a VPN are forwarded

9 LAN interface set up

The LAN interface is made of 4 Ethernet switched ports or of 2 Ethernet switched ports and 2 serial ports or 2 serial port and 1 USB port.

On that interface, the following IP addresses must be entered :

The router IP address on the LAN interface *.

The IP address pool assigned to the remote users when they connect.


* The administration server is located at that address.

On the LAN interface, the RAS-3G can behave like a DHCP server.

Remark about IP addresses assignment rules :

The RAS-3G router will be able to route frames between the LAN and the WAN interface only if the IP address assigned to the network connected to the LAN interface is different from the one assigned to the WAN interface.

Moreover , through a VPN, the LAN IP address must be different from the remote LAN IP address



9.1 IP protocol

- Click the « **Configuration** » menu and then « **LAN interface** » and then “**IP protocol**”.

“IP address” parameter :

Enter the IP address assigned to the router over the LAN interface.

That IP address will have to be entered to display the administration server of the router.

“Netmask” parameter :

Enter the IP netmask assigned to the LAN

“Start of users IP address pool” & “end of users IP addresses pool” parameters :

That parameters define the pool of addresses which will be assigned automatically to remote user's PC when they will connect to the router.

Enter the start address and the end address.

Remark :

After the LAN IP address of the router has been modified, it is necessary to reboot the unit.

If VPNs have been created, they must be launched again after the LAN IP address has been modified.

To launch the VPNs again after the LAN IP address has been modified,

- Select the « network » menu and then the « **VPN** » menu,
- Click the « Properties » button in front of the « type of VPN » field, and then on the “OK” button of the window entitled « VPN properties ».
- Click the « Modify » button in front of the « VPN connection » field, and then on the “OK” button.

If the DHCP server is used, it must be launched again after the LAN IP address has been modified.

To launch again the DHCP server after the LAN IP address has been modified,

- Select the « LAN interface » menu and the « DHCP server » menu,
- Unselect the « Enable the DHCP server » checkbox, and then select it again.

9.2 DHCP server

Over the LAN interface, the RAS-3G router can behave like a DHCP server.

- To configure the DHCP server function,** select the « **Setup** » menu and then « **LAN interface** » and then « **DHCP server** ».

“Activate DHCP server” checkbox :

Select that checkbox to enable the DHCP server.

“IP address pool start” & “IP addresses pool end” parameters :

That parameters define the range of IP addresses which can be assigned by the RAS-3G to the DHCP client devices.

“Netmask” & “default gateway” parameters :

Enter the netmask of the network connected to the LAN interface and the default gateway address.

« Primary DNS IP address » & “secondary DNS IP address” parameters :

Enter the IP addresses of the domain name servers.; the DHCP server will communicate that information to the DHCP client devices.

“Client MAC address” “Client IP address” table :

If a fixed IP address must be assigned to the devices connected to the LAN interface, enter the MAC address and the fixed Ip address of each of these devices.


10 UMTS – GSM-GPRS-3G/EDGE interface set up

The RAS-3G router's UMTS – GSM-GPRS-EDGE interface is configured through the WAN interface menu :

The 3G modem interface is configured through the « Modem » page.

The PPP interface to the provider is configured through the « Connection » page.

The conditions at which the 3G connection can be reset is configured through the « Control » page.

Remark : Once that operations will have been carried out, check the Reception indicator  is permanently ON. It signifies the RAS-3G is now connected to the UMTS network.

10.1 Modem menu

- Select the « **Configuration** » menu and then « **WAN interface** » and then “**Connection**”.

“APN” parameter :

Enter the APN code assigned by the GSM operator.

“User name” & “password” parameters :

Enter the user name and password assigned by the GSM operator.

Remark : If no user name or password have been assigned by the GSM operator, enter at least an alphabetic character in each field.

10.2 Connection menu

- Select the « **Configuration** » menu and then « **WAN interface** » and then “**Connection**”.

“Obtain an IP address automatically” checkbox :

Set that option if the provider assigns automatically an IP address to the router through the air interface each time it connects to the 3G or GSM network.

Remark : In most cases, and in particular when the RAS-3G is connected to the Internet, that checkbox must be selected.

“IP address” & “netmask” parameter :

Enter the fixed IP address and netmask assigned to the router if it not assigned through the air interface.

“Obtain DNS IP addresses automatically” checkbox : Select that checkbox if the Domain name servers IP addresses are provided automatically through the air interface.

Remark : In most cases, and in particular when the RAS-3G is connected to the Internet, that checkbox must be selected.

“Primary DNS IP address” & “secondary DNS IP address” parameters :

Enter the IP addresses of the domain name servers if they are not assigned through the air interface.

“Activate network address translation” checkbox :

If that option is selected, the source IP address of any frame coming from a device connected to the LAN interface and routed to the WAN interface, is replaced by the router WAN IP address.

Remark : In most cases, and in particular when the RAS-3G is connected to the Internet, that checkbox must be selected.

“SMTP server” parameter :

Enter the address of the SMTP server for outgoing mails (ex : smtp.nerim.net)

“Source account e-mail address” parameter :

Enter the email address attached to the account.

10.3 “Control” menu

The RAS-3G router may not detect that the 3G connection has been cleared ; it is why, the router can send a periodical PING to a particular address.

If one that PING does not receive an answer, and after several retries, the 3G connection is reset by the RAS-3G router.

- To set-up that function, select the « **Configuration** » menu and then « **WAN interface** » and then “**Control**”.

“Enable the ping control” checkbox :
select that checkbox.

“IP address to ping” parameter :
Enter the IP address of the server to which the RAS-3G will transmit periodically a PING to control the connection works correctly.

“Ping period” parameter :
Enter the value of the period of the PINGS.

“Ping retries” parameter :
If a PING does not receive an answer, the router will repeat PINGS at a high frequency. If that high frequency PINGS do not receive an answer after a certain number of retries, the connection is reset. Enter the number of times the router has to repeat the PING request at a high frequency before declaring the connection in failure.

11 Setting up the DynDNS service

Remark :

The DynDNS service is free; but the dyndns domain name can be cancelled if it is not periodically used.

The DynDNS service cannot be used to reach the antenna of the RAS-3G router if the IP address assigned to the RAS-3G router is not a public IP address.

If the IP address assigned to the antenna of the router on the 3G network is public but not fixed, it is possible to use the DynDNS service to set a connection from a device connected to the internet towards a device connected to the RAS-3G router.

To enable the DynDNS service proceed as follows :

- Reserve a dynDNS domain name on the dyndns.org web site.

For instance mymachine.dyndns.org.

- Select the « Set up » menu, and then WAN interface, and then “dynamic IP address” .

« Enable » checkbox :

Select that checkbox.

« DNS account login » parameter :

Enter the login assigned by dyndns.

« DNS account password » parameter :

Enter the password assigned by dyndns.

« Hostname » parameter :

Enter the DynDNS domain name (for instance mymachine.dyndns.org).

- When you wish to set a connection toward the RAS-3G (PPTP, TLS, VPN ...), enter the DynDNS host name instead of the antenna IP address of the RAS-3G router.

12 Creating VPN connections between routers

12.1 Principles

A VPN tunnel is a safe link set between two end-points routers over an IP network : Both routers authenticate, data are encrypted and each device of a LAN can exchange data with each device of the other one.

To get more explanations about how VPNs work, refer to appendix 1.

25 VPNs can be set on the WAN interface of the RAS-3G router.

Two types of VPN can be set : TLS VPN and IPSec VPN.

IPSec has the advantage to be a standard solution.

TLS is easier to employ because the transport layer is TCP or UDP; it is why, it can be easily used when the VPN must pass through several or even numerous company routers.

Once a type of VPN (TLS or IPSec) has been selected, all the VPN set with the RAS-3G router will be of the same type.

Two steps are necessary to configure the RAS-3G to create VPN connections between routers :

1st step : Select the VPN type and set up the VPN parameters


2 types of VPNs can be used to connect RAS-3G routers together or with other type of routers: IPSec or TLS/ SSL

Once a type of VPN has been selected, it applies to all the connections with remote routers.

2nd step : Creating VPN connections


A connection can be an incoming connection or an outgoing connection.

If a connection is an incoming connection, the local router is named "VPN server" and the remote router is a "VPN client".



To create VPN connections between routers,


- select the « **Setup**» menu and then « **Network**» and then “VPN connections”.



12.2 IPSec VPN connections

12.2.1 Configuring the IPSec protocol

- Select the **“Setup”** menu, the **“network”** menu and then **“VPN connections”**.
- Select the **“Ipsec”** type of VPN,
- Click **“Properties”**.



Connection parameters - Windows Internet Explorer

about:blank

IPSec parameters

Select the protocol used for IPSec connections. With AH protocol, there is no encryption but authentication only.

Protocol : ESP

Select the authentication used for IPSec connections.

WARNING :
- If the product is behind a router which makes address translation or port forwarding (DNAT) and you wish to configure an ingoing IPSec connection, you must select an authentication by certificate.

Authentication by : Pre Shared Key

Key value :

Warning : The Pre Shared Key is global for the product.
The same value will be used for remote connections and for L2TP/IPSEC remote user access.

Select encryption and authentication algorithms for IPSec Phase 1 and Phase 2.

Phase 1 : Auto Phase 2 : Auto

DPD (Dead Peer Detection) is used to detect the tunnel death and, in this case, delete IKE and IPSec associations for this peer.

DPD keepalive period : 30 sec Connection death timeout : 2 min

PFS (Perfect Forward Secrecy) : Modify the default value (YES) only for interoperability purpose.

PFS : Yes

OK Cancel Default configuration

Terminé Internet 100%

“ Protocol ” parameter :

AH ((RFC2402) provides integrity, authentication, replay resistance and non-repudiation but not encryption.

select AH, if no encryption is required or if NAT traversal is required.

ESP provides the same services plus encryption.

If ESP is selected, an encryption and an authentication protocols must be selected.

“Authentication & encryption key” parameters :

Authentication an encryption can be carried-out with a pre-shared key or a certificate.

“Pre-shared key” value :

The pre-shared key value applies to all the connections.

The maximum length of the key is 40 characters.

The same preshared key value will be used for remote users L2TP / IPSec connections.

“Certificate” value

The RAS-3G router is delivered with a certificate stored into the product in our factory.

To add a certificate, refer to the “Security” menu.

“Encryption and hash algorithm phase 1” & “Encryption and hash algorithm phase 2” parameters :

That parameters allow to define the encryption and hash algorithms in use during the phase 1 of the exchanges between the end-points (VPN set-up) and during the phase 2 (data exchange).

The default value is Auto; in that case both end-points will negotiate a common algorithm.

“DPD request period” parameters :

A DPD request (also called Keepalive message) is a message sent periodically by each end-point to the other one to make sure that the VPN must be left active.


This parameters sets the amount of time (in seconds) between two of these requests.

“Connection death time-out” parameters :

This parameter defines the maximum amount of time (in seconds) a VPN connection will stay established if no traffic or no DPD request message are received from the remote point.

ATTENTION : Once the parameters of the IPSEC connection have been selected, click the OK button and then the Save button.

12.2.2 Configuring an outgoing IPSec connection



To set an outgoing VPN connection,

- Come back to the “VPN connections” screen,
- Click the “add a connection” button.

The screenshot shows the 'Remote connection configuration' window in Windows Internet Explorer. The window has a title bar 'Remote connection configuration - Windows Internet Explorer' and a toolbar with 'about:blank'. The main content area contains the following fields and options:

- Active:** A dropdown menu set to 'Yes'.
- Protocol:** A dropdown menu set to 'IPSec'.
- Name:** A text input field.
- Select the connection (Ingoing or Outgoing) you wish to configure.** A dropdown menu set to 'Outgoing'.
- Informations about the remote network.**
 - Remote WAN IP address:** A text input field.
 - Remote LAN address:** A text input field.
 - Remote LAN netmask:** A text input field.
- You choose an authentication using Pre Shared Key.** A checkbox is checked.
- Use a specific key for this connection:** A checkbox is unchecked.
- Key value:** A text input field.
- My WAN IP address:** A text input field.

At the bottom of the window are 'Ok' and 'Cancel' buttons. The status bar at the very bottom shows 'Terminé' and 'Internet'.

Give a name to the connection and select the “Outgoing” option.

‘Remote WAN IP address’ parameter :

Enter the IP network address and netmask assigned to the remote router over its WAN interface..

“Remote LAN address & Remote LAN netmask” parameters :

Enter the IP network address and netmask assigned to the remote LAN.

• **Preshared key**

If the preshared key used by the connection is the general PSK entered in the “VPN” menu, no additional parameter has to be entered.

If a particular PSK must be used, complete the configuration of the connection as explained below.

“Unique PSK for this node” parameter :

Select that option if a particular PSK key has to be used for this connection.

"PSK value" parameter :

Enter the value of the PSK.

"My WAN address" parameter :

Enter the IP address of the router on the WAN interface.


- **Certificate**

"My subjectAlt name" & "Remote subjectAlt name" parameters :

Paste the field "SubjectAltName" of the active certificate of the router you are configuring and the one of the remote router.


Attention : For ETIC certificates, this field is the Email field

12.2.3 Configuring an incoming IPSec connection



To set an ingoing VPN connection,

- Come back to the “VPN connections” screen,
- Click the “add a connection” button.



Give a name to the connection and select the “ingoing” connection direction option.

“Remote WAN IP address” parameter :

Enter the IP network address and netmask assigned to the remote router over its WAN interface.

“Remote LAN address” & “Remote LAN netmask” parameters :

Enter the IP network address and netmask assigned to the remote LAN.

• Preshared key

If the key used by the connection is the general PSK entered in the VPN menu, no additional parameter has to be entered.

If a particular PSK must be used, carry out the configuration of the connection as explained below.

“Use a specific key for this connection” parameter :

If that option is not selected, the preshared key entered in the VPN configuration screen will be used by the router.

If that option is selected, enter the specific key.

“My WAN address & Remote WAN address” parameters :

Enter the WAN IP address of the router and the WAN IP address of the remote router.

Attention : For ETIC certificates, this field is the Email field

- **Certificate**

“My subjectAlt name” & “Remote subjectAlt name” parameters :

Paste the field "SubjectAltName" of the active certificate of the router you are configuring and the one of the remote router.

Attention : For certificates delivered by ETIC TELECOM, this field is the Email field.

12.3 TLS VPN connections

12.3.1 Configuring the TLS-SSL protocol

- Select the “**Setup**” menu, the “**network**” menu and then the ‘VPN connections” menu.
- Select the “**TLS**” VPN type and click “Properties” .

The screenshot shows a web browser window titled "Connection parameters - Windows Internet Explorer" with the address bar showing "about:blank". The main content area is titled "TLS parameters" and contains the following fields and instructions:

- Define the port used for Ingoing and Outgoing nodes.**
Warning, this value must be different from the one used for remote user connection.
Port number : 1195 Protocol : UDP
- Choose a VPN network address used for Ingoing nodes :**
VPN network address : 172.16.0.0 VPN network netmask : 255.255.255.0
- Define the time to detect the dead of the remote end.** This value is ONLY used for Ingoing nodes. An Outgoing node will automatically use the value pushed by the remote Ingoing node.
Dead detection time : 5 min
- Packet retransmit timeout on TLS control channel if no acknowledgment from remote within n seconds.**
Retransmit timeout : 30 sec
- Select the encryption algorithm and the message digest algorithm used for Ingoing and Outgoing nodes.**
Encryption algorithm : BlowFish Message digest algorithm : MD5 (128 bits)

At the bottom, there are three buttons: "OK", "Cancel", and "Default configuration". The browser's status bar at the bottom shows "Terminé" and "Internet".

“Port number” & “protocol” parameters :

Select the port Nr and the type of level 3 protocol used to transport the TLS VPN; UDP will be preferred.

Attention : The port number value must be different from the one used by remote users.


“VPN network address” & “VPN network netmask” parameters :

The TLS VPN server router assigns automatically an IP address to the VPN client router. That VPN IP address must not be confused with the WAN interface IP address.

Attention :

The VPN IP network address field must be different from the WAN network IP address .

The number of VPN addresses cannot be greater than 255; the netmask cannot exceed 255.255.255.0.



“Connection death time-out” parameter :

This parameter defines the maximum amount of time (in seconds) a VPN connection will stay established before being cleared if no response to the VPN control message has been received from the remote router.

“Packet retransmit time-out” parameter:


A control message (also called Keepalive message) is sent periodically by the VPN server router to make sure that the VPN must be left active.

This parameters sets the amount of time (in seconds) the server will wait for the response before repeating it.

“Encryption algorithm” & “Authentication algorithm” parameter :

That parameters allow to define the encryption and hash algorithms in use.

12.3.2 Configuring an outgoing TLS connection



- Select the **“Setup”** menu, the **“network”** menu and then the **“VPN connections”** menu.
- Click the “add a connection” button.
- Give a name to the connection and select the **“Outgoing”** connection direction option.

“Login & Password” parameter:

Enter the login and password, the router will have to use to authenticate.


Remote WAN IP address / URL parameter :

Enter the IP address of the remote router or its DNS name.


“Remote WAN IP address” ” parameters :

Enter the IP network address and netmask assigned to the remote router over its WAN interface.

12.3.3 Configuring an incoming TLS connection



- Select the “**Setup**” menu, the “**network**” menu and then the “**VPN connections**” menu.
- Click the “add a connection” button.



Give a name to the connection and select the “**incoming**” connection direction option.

“Remote router Login” & “Remote router password” parameters :

Enter the login and password of the remote router

The remote router has to use that login and password to authenticate.

“Remote LAN address” & “Remote LAN netmask” parameters :

Enter the IP network address and netmask assigned to the remote LAN.

“Common name” parameters :

Enter the remote router certificate common name.

Attention : For ETIC certificates, this field is the Email field.


13 Routing functions

13.1 Basic routing function

Once an IP address has been assigned to the R2 router on the LAN interface and another one on the WAN interface (see drawing hereafter), the RAS-3G R2 router is ready to route frames ...

... between devices connected to the remote LAN network like RL1, and devices connected to the LAN network like L1 through a VPN;

... between devices connected to the WAN network like W1, and devices connected to the LAN network like L1




Remark 1 : Firewall rules must be set to authorize WAN to LAN transfer.

Remark 2 : A default gateway address must be entered in each device of the different networks.

13.2 Static routes

However, the router R2 is not able to route frames between a device like L1 belonging to the LAN network and a device connected to “network 6” (see the drawing hereafter).



In that case, it is necessary to enter the route to that hidden “network 6”; that route is called a static route.

A static route consists in a table which describes a destination network (IP address and netmask) and the IP address of the neighbour router through which an IP packet to that destination must pass.

Router 2 static routes :

Active	Route name	Destination	Netmask	Gateway
Yes	Network 6	192.168.6.0	255.255.255.0	192.168.5.1
Yes	Network 1	192.168.1.0	255.255.255.0	192.168.2.1
Yes	Network Remote WAN	192.168.4.0	255.255.255.0	192.168.5.128

Remark :

It is not necessary to enter in the router R2 the static route to the WAN network nor to the remote LAN network, that routes have been automatically created by the router respectively when the WAN IP address has been entered and when the VPN has been configured.

To set a static route,

- Select the “**Configuration**” menu, the “**network**” menu the “**Routing**” menu and then “**Static routes**”.
- click the “Add a route” button.

“Destination IP address” & “netmask” parameters :

Enter the destination network IP address and netmask.

“Gateway IP address” parameters :

Enter the Ip address of the gateway through which the IP packets intended for that network must pass.

13.3 RIP protocol

RIP (**R**outing **I**nformation **P**rotocol) is a routing protocol which enables each router belonging to a network to acquire the routes to any subnet.

The principle is as follows :

Routing table

Each router holds a routing table.

Each entry of the table consists in the destination subnet address and the adjacent router address leading to that subnet.

Routing table broadcasting :

Each router broadcasts its table.

Routing table update :

Each router updates its own table using the tables received from the other ones.

To enable RIP,

- select the « **Setup** » menu, the “Routing” menu and then the “RIP” menu».
- Select the ‘Enable RIP on LAN interface” and the “Enable RIP on WAN interface” options.

14 Address and port translation

The RAS-3G provides the capability to replace the original source IP address and the destination port and IP address in particular situations.

14.1 Port forwarding

Port forwarding consists in transferring the IP frames addressed to the RAS-3G antenna IP address (WAN IP address) at a particular port number, to a particular device connected to the LAN interface.

The transfer criteria is the port number; the port number is used as an additional address field.

When a frame is addressed to the RAS-3G router with a particular registered port, it is transferred to a particular device connected to the LAN interface.


Example :

Let us suppose the PC named "W1" connected to the Internet has to send frames to the device PLC1 connected to one Ethernet port of the RAS-3G router.

If a VPN cannot be set, the solution can be to use the Port forwarding function :

When W1 needs to transmit frames to PLC1, it addresses the frames to the RAS-3G router on a chosen and agreed port.

The router checks the frame, replaces the destination address by the IP address of the device on the LAN interface, and eventually changes the port number.



The port forwarding table will be

IP frames received by the router on its 3G interface (WAN)		Modified forwarded frame	
@IP	Port	Device IP@	Port
62.10.10.7	102	192.168.0.15	102
62.10.10.7	8080	192.168.0.15	80
62.10.10.7	502	192.168.0.16	502
62.10.10.7	80	192.168.0.17	80

Remark :

Port forwarding, can be used only if the address assigned to the RAS-3G router over the 3G network is a public IP address.

If it is a dynamic IP address, DynDNS can be used.

Port forwarding is a security defect; it must be used only if the devices connected to the LAN interface of the RAS-3G are themselves protected (password ...) and not dangerous.

To set the Port forwarding function,

- select the “network” menu and then the “Port forwarding” menu.
- Click “Add a DNAT” rule.

14.2 Advanced network address and port translation

14.2.1 Principle

This function is available in RAS-3G-1400, RAS-3G-1201, RAS-3G-1220, RAS-3G-1230 routers only.

That function consists in replacing the source port and IP address or the destination port and IP address of particular frames received by the router on its interfaces according to configured rules.

It applies to all the frames received by the router on any of its two interfaces except to the IP packets contained in a remote user PPTP or TLS connection.


It applies as well to frames the destination address of which is the RAS-3G router itself or to frames the destination IP address is a device belonging to the LAN subnet, or to the WAN subnet or to another network.

One brings out

the DNAT function which consists in replacing the destination port and IP address.

the SNAT function which consists in replacing the source IP address.


Because the DNAT and SNAT functions modify the IP addresses of the IP packets processed by the RAS-3G router, and because the firewall filters that frames, it is very important to understand in which order that different functions are carried out.



14.2.2 Configuration

To set the advanced address translation functions,

- select the “**Setup**” menu, “**Network**”, and then the “**Advanced NAT**” menu.



To create a new DNAT rule

- Click “Add a DNAT” rule.
- Select “Yes” to enable the rule.
- Enter the replacement criterion :
 - Source IP address & Destination IP address.
 - Protocol (TCP, UDP, ...)
 - Source port & Destination port
- Enter the new destination port number and IP address.

DNAT rules - Windows Internet Explorer

about:blank

IP address field:

- Leave the address blank to apply the rule to all IP addresses.
- Enter just an IP address (ex: 192.168.10.1) or a network IP address (ex: 192.168.0.0/24 or 192.168.0.0/255.255.0).

Port field :

- Leave the port blank to apply the rule to all ports.
- Enter a numeric port value under the form xx to specify a single port (e: 80 for HTTP)
- Enter numeric ports values under the form xx.yy,...zz to specify several ports (ex: 21,80 to specify FTP and HTTP)
- Enter numeric ports values under the form xx:yy to specify a port range (ex: 80:90 to specify all ports between 80 and 90)

New destination field :

- Enter just an IP address (ex: 192.168.10.1) or an IP address and a port (ex: 192.168.10.1:8080).
- Enter a network IP address (ex: 192.168.10.0/24) for a 1:1 mapping.
- Leave the address blank or enter "0.0.0.0" not to translate (Null NAT).

Frame to trigger :

Active

Source IP address

Destination IP address

Protocol

Source port

Destination port


Translation :

New destination

Terminé Internet 100%

To replace the source IP address & destination port

- Click “Add a SNAT” rule.
- Select “Yes” to enable the rule.
- Enter the replacement criterions :
Source & Destination IP address.
Protocol (TCP, UDP, ...)
Source & Destination port
- Enter the new source IP address.



SNAT rules - Windows Internet Explorer

about:blank

IP address field:
 - Leave the address blank to apply the rule to all IP addresses.
 - Enter just an IP address (ex: 192.168.10.1) or a network IP address (ex: 192.168.0.0/24 or 192.168.0.0/255.255.0).

Port field :
 - Leave the port blank to apply the rule to all ports.
 - Enter a numeric port value under the form xx to specify a single port (e: 80 for HTTP)
 - Enter numeric ports values under the form xx,yy,...,zz to specify several ports (ex: 21,80 to specify FTP and HTTP)
 - Enter numeric ports values under the form xx:yy to specify a port range (ex: 80:90 to specify all ports between 80 and 90)

New source field :
 - Enter just an IP address (ex: 192.168.10.1) or an IP address and a port (ex: 192.168.10.1:8080).
 - Enter a network IP address (ex: 192.168.10.0/24) for a 1:1 mapping.
 - Leave the address blank or enter "0.0.0.0" not to translate (Null NAT).

Frame to trigger :

Active

Source IP address

Destination IP address

Protocol

Source port

Destination port

Translation :

New source

Terminé

Internet 100%

15 VRRP redundancy

That function is available only in RAS-3G-1400, RAS-3G-1201, RAS-3G-1220, RAS-3G-1230 routers

15.1 Principle

VRRP is a protocol designed to increase the availability of the default gateway of a subnet.

Thanks to VRRP, a group of two or more routers can service the hosts of one subnet instead of only one usually; only one router of that group actually routes frames; if it fails another one of the group takes its place.

The routers belonging to a VRRP group must be connected to the same Ethernet segment.

VRRP works as follows :

An usual IP address is assigned to each router of the group.

An additional and common IP address, called the virtual IP address is assigned to all the routers of the group. This virtual address is the address which must be stored as the default gateway address in all the host devices belonging to the subnet.

A priority index is assigned to each router of the group. Using that index, the routers of the group can elect a master router; the master router is the one which has the greatest priority code. The other routers are the backup routers.

The master router is the only one to answer to the ARP requests and route actually frames. It uses the virtual IP address and the virtual MAC address if that option has been selected.

In case of failure of the master router, another master router is elected. It replaces the router in failure. It will use the same virtual IP address and the virtual MAC address as the previous master router.

The RAS-3G router manages that protocol as well on the LAN and on the WAN interface.

15.2 Configuring VRRP on the LAN interface

To enable and configure VRRP,

- select the “**Setup**” menu, the “**network**” menu and then the “**VRRP**” menu.

«Enable VRRP on the LAN interface» parameters :

Tick that checkbox to enable VRRP on the LAN interface.

«VRRP Id (1-255)» parameter:

Assign an identity code to the routers group between 1 and 255.

The same identity code must be assigned to all the routers of the group.

«Virtual IP address» parameter :

Enter the IP address the elected master router will use to answer to ARP requests.

«Priority (1-255)» parameter :

Assign a priority index to the router

The router which has the greatest index will become the master router.

«Use a virtual MAC address» parameter :

A virtual MAC address can be associated to the virtual IP address.

If that option is selected, the elected master router will answer to ARP requests by using that virtual MAC address.

That MAC address is 00-00-5E-00-01-XX, where XX is the VRRP Id of the group coded in hexadecimal.

15.3 Configuring VRRP on the WAN interface

To enable and configure VRRP,

- select the “**Setup**” menu, the “**network**” menu and then the “**VRRP**” menu.

«Enable VRRP on the WAN interface» parameter :

Tick that checkbox to enable VRRP on the LAN interface.

«VRRP Id (1-255)» parameter :

Assign an identity code to the routers group between 1 and 255.

The same identity code must be assigned to all the routers of the group.

«Virtual IP address» parameter :

Enter the IP address the elected master router will use to answer to ARP requests.

«Priority (1-255)» parameter :

Assign a priority index to the router

The router which has the greatest index will become the master router.

«Use a virtual MAC address» parameter :

A virtual MAC address can be associated to the virtual IP address.

If that option is selected, the elected master router will answer to ARP requests by using that virtual MAC address.

That MAC address is 00-00-5E-00-01-XX, where XX is the VRRP Id of the group coded in hexadecimal.

16 Remote users connections service

The RAS-3G provides a full remote user connection function called RAS :

- The remote user authenticates using the login, password and eventually a certificate; the router accepts the connection only if the remote user belongs to the user list.
- Individual access rights are automatically allocated to the remote user.
- An IP address belonging to the LAN network is automatically assigned to the remote PC.
- Data are encrypted (TLS and L2TP / IPSec only).
- The connection is logged.
- Moreover, the RAS-3G is compatible with the M2Me_Connect service when setting a direct connection is not possible.

To setup the remote user connection service, the following steps must be carried out :

- Step 1 :

Configure a [PPTP or TLS or L2TP connection](#)

or select the [M2Me_Connect service configuration](#) menu.

- Step 2 :

Complete the [user list](#)


- Step 3 ::

Define the [firewall rules](#) to limit the rights of the remote users

17 Remote users connections

17.1 Principles

A remote user connection is a tunnel set between a remote PC and a router providing the RAS function (Remote Access Service), like the RAS-3G.



A remote user connection provides security and simplicity advantages :

- The remote user is identified with a login in and password or eventually a certificate.
- The data is encrypted (TLS or L2TP).
- An IP address belonging to the local network is automatically assigned to the remote user's PC.

The RAS-3G manages PPTP and TLS or L2TP remote connections.

Only one type can be selected. It will apply to all the remote users connections.


A PPTP is the simplest type of remote user connection; data is not encrypted.
The remote user can be identified only with a login and password.

A TLS connection provides encryption; moreover, the remote user can be identified with a log in and password and with a certificate if necessary.

17.2 Configuring a TLS connection

The M2Me_Secure software provided by ETIC TELECOM is a Windows TLS client software. Installed on a PC running Windows XP or Seven, M2Me_Secure makes TLS connections from a remote PC to the RAS-3G easy; moreover it includes a connection book in such a way one just need a click to connect to a remote site.


We describe hereafter how to configure the router and the M2Me_Secure software to set a TLS VPN between both.



Step 1 : Router configuration

To configure a remote user TLS connection,

- select the “**Setup**” menu, the “**Remote users**” menu and then the “**User list**” menu.



- Select the VPN type “ TLS”.
- Click the “Properties” button and set the parameters.

"Port number" & "Protocol" :

Select the port Nr and the type of level 3 protocol used to transport the TLS VPN; UDP will be preferred.

Attention :

The selected port number assigned to the remote users connections must be different from the one used for VPN connections between routers if such VPN connections have been configured.

"Remote Users authentication" parameters :

Authentication and encryption can be carried-out with a pre-shared key or a certificate.

If the **"Login/password"** is selected, the remote user is authenticated with a login and a password.

If the **"Login/password and Certificate" value** is selected, the remote PC is authenticated with the certificate and the user with a login and password. In that case, the PC certificate must be stored in the user list.

«Encryption algorithm» & «Message digest algorithm» parameters :

Leave the default values.

Step 2 : Configure the M2Me_Secure software

For detailed information, report to the M2Me_Secure manual.

- Click « Menu » and then « New site ». The Site configuration window is displayed.
- Select the « General » tab and enter a site name.
- Select the « Connection » tab; select the option "That site can be reached through the Internet."
- In the field « Host name or IP address », select the router IP address or DynDNS name or DNS name.
- Select the « Advanced tab » ; select the level 3 protocol (UDP or TCP), the port number and the encryption algorithm.

These parameters must have the same values must in the PC and in the router.


17.3 Configuring a PPTP connection

We describe hereafter how to configure the router and the PC to set a PPTP remote user connection between them.

Step 1 : Router configuration

- select the “**Setup**” menu, the “**Remote users**” menu and then the “**User list**” menu.
- Select the VPN type “PPTP”.

Remark : The “properties” button allows to modify the authentication protocol; leave the default configuration if the PPTP client is a PC running Windows.



Step 2 : Set up a PPTP connection on the PC side.

18 M2Me_Connect service

This function is available in RAS-3G-1400, RAS-3G-1201, RAS-3G-1220, RAS-3G-1230 routers only.

18.1 Overview

The M2Me_Connect service simplifies the connection of a remote PC to a machine through the Internet.

It provides a solution when a direct PPTP or TLS connection described before shows itself impossible in particular when the IP address assigned by the provider to the RAS-3G antenna (WAN interface) is not a public IP address.


The M2Me_Connect service solves that difficulty :

The PC does not connect directly to the RAS-3G; both the PC and the router connect to the "M2Me_Connect" service.

Once both parties have been authenticated by the M2Me_Connect service with their own certificate, a TLS VPN is set from end to end from the PC to the RAS-3G router.

The remote user identity is checked by the router to verify he or she belongs to the user list stored in the RAS-3G router.

Finally, individual access rights are assigned to the remote user depending on his or her identity.



18.2 Configuring a M2Me_Connect connection

Step 1 : Router configuration

- Select the « **Setup** » menu, the « **Remote users** » menu, the “**M2Me_Connect**” menu, and then the “**Connection**” menu.

« Activate » parameter:

Select the checkbox

“TCP ports” and “UDP ports” parameters :

Select the protocol (UDP and or TCP) and the ports numbers the router must check to set a connection to the M2Me_Connect service.

We advise to select only the TCP protocol because providers sometimes forbid UDP to avoid unsolicited frames coming from the internet to the antenna of the router.

- Test the connection

Click the “Control” menu, and press the “connect now” button.

Go to the “Diagnostic” menu, “Network status” menu and then “M2Me”.

When the connection between the router and the M2Me_Connect service is established, the port number and protocol are displayed.

- Deselect the ports numbers needlessly selected

If too many ports have been selected, the connection delay may be long; it is why, we advise to unselect all the ports except the one which has finally been successful.

Step 2 : M2Me_Secure software configuration (PC side)

- Click « Menu » and then « New site ». The Site configuration window is displayed.
- Select the « General » tab and enter a site name.
- Select the « Connection » tab; select the option “That site can be reached through the Internet and the “M2Me_Connect” option.
- Enter the product key of the router; it can be pasted from the “About” menu of the router.

19 Users list


Storing at least an authorized user in the users list is necessary if a remote user wishes to connect to the RAS-3G with a PPTP or a TLS or a L2TP/IPSec remote user connection.

The users list registers 25 authorised remote users forms.

Each user form stores the identity of the user (Login and password), his email address to send alarm emails and the filter assigned to him.

To display the user list,


- select the “**Setup**” menu, the “**Remote users**” menu and then the “**User list**” menu.



Attention :

Coming from factory, a default user is registered; his login is admin and the password is also admin. After the test phase, we advise to modify these login and password.

To add a user form



Users parameters - Windows Internet Explorer

about:blank

Active : Yes

Full name :

User name :

Password :

Confirm password :

E-mail :

Firewall filter: None

The following VPN parameters depend on the remote users connections VPN selected.

VPN connection : SSL / TLS

Authentication by: Certificate

Enter the certificate common name (CN) the user will use to authenticate.

Common name: *

Ok Cancel

Terminé Internet 100%

- Click the “add a user ” button

“ Active (value Yes or NO)” :

Select “No” if you want to prevent the user to access the network.
Select “yes” to authorize the user to access the network.

Full name :

It is the name displayed in the user list.

Login & password

The login and the password will have to be entered by each user at the beginning of the remote connection.

E-mail :

The RAS-3G will send an email to that address in two situations :

Alarm email : the RAS-3G sends an alarm email to the defined user If the input 1 is closed or opened (if that option has been set).

Internet connection email : Once connected to the Internet, the RAS-3G will send to the demanding user an email containing the dynamic IP @ assigned to the RAS-3G by the provider. (See OPERATION chapter).

Firewall filter :

Select a filter in the list.

A filter defines a domain of the local network.

Thus, once assigned to a user, a filter limits his or her access rights.

20 Firewall

20.1 Overview

The firewall filters IP packets between the WAN and the LAN interface of the RAS-3G router. It is divided in 3 particular filters :

- **The remote users filters**

The function of the remote users filters is to limit the IP domain an authenticated remote user can reach when he connects to the RAS-3G router through the Internet.

The remote users filters filter the destination IP address and port number of the IP packets included inside a PPTP or TLS or L2TP remote user connection.

Thus the IP addresses checked by the remote users filters are LAN IP addresses.

25 remote users filters can be created and assigned individually to each of the users declared in the user list.

The source IP address of the packets is not checked by the remote users filters because the filters apply to the remote users connections according the login and password of the remote user checked when the remote user connection is set.

- **The main filter**

It filters IP packets whether carried inside one of the VPNs or outside a VPN.


The main filter checks source and destination IP addresses and the source and destination ports.

The main filter does not check the IP packets included in a remote user connection. That packets are checked by the remote users filter.

The main filter does not check the IP packets defined in the "Port forwarding" table. That packets are directly forwarded to the defined device (see [Port forwarding](#)).

- **The deny of service filter** is made to usual attacks coming from the Internet. That filter cannot be configured.

The firewall of the RAS-3G firewall can thus be represented by the drawing hereafter :



20.2 Main filter

The main filter applies to all the IP packets except to the ones included in remote users connections.

To recognize a TLS remote user connection, the router detects the port number.

20.2.1 Main filter Overview

- **Main filter structure**

For a better organisation, the main filter is divided in two tables; both having the same structure.

The “VPN” filter : It filter the packets transmitted inside the VPNs.

The “WAN” filter : It filters the packets transmitted outside the VPNs

Each of that two filters is made of

- a filter policy
- and
- a filter table each line of which is a filter rule

- **Main filter default policy**

The default policy is the decision which will be applied if a packet does not match any of the rules of the filter.

The WAN to LAN and the LAN to WAN traffic are regarded separately because the decision can be opposite for a packet coming from the WAN or coming from the LAN :

WAN to LAN : The default policy can be “Accept” or “drop”.

LAN to WAN : The default policy can also be “Accept” or “drop”.

For instance, if the default policy assigned the WAN to LAN traffic is “drop”, it means that an IP packet which does not match any of the rules of the main filter will be rejected.

- **Main filter table**

The main filter is a table, each line being a rule.

Each rule of the filter is composed a several fields which defines a particular data flow and another field which is called the action field.

The fields which define the data flow are :

- Direction (« WAN to LAN » or « LAN to WAN »),
- Protocol (TCP, UDP...),
- IP@ & port number, source & destination.

The Action field can take two values

- Accept : To authorize the data flow to be forwarded to the router interface.
- Drop : To drop the packet which matches the rule.

- **How does the main filters works**

When the firewall receives a packet, it checks if it matches the first rule..


If it does, the decision is applied to the packet according to the “Action” field.

If it does not, the firewall checks if it matches the second rule; and so on.

If the packet does not match any of the rules of the table, the default policy is applied to the packet (drop or reject).

20.2.2 Configuring the main filter

Select the “**Security**” menu and then “**Firewall**” and “**Main filter**”.



The “Main filter” page is divided in two parts :

WAN traffic rules :

The first part, entitled “WAN” traffic rules, is made to define how the IP packets **not carried in a VPN**, have to be filtered.

VPN traffic rules :

The second part, entitled “VPN traffic rules” allows to define how the IP packets **carried inside the VPNs** have to be filtered.

Configure successively the WAN traffic rules using the same method.

Step 1 : Select the default policy

“LAN to WAN” parameter :

That parameter sets what the filter will decide if an IP packet coming from the LAN does not match any of the rules of the filter :

If the value “Accept” is selected, the IP packet will be transmitted to the VPN.

If the value “Drop” is selected, the IP packet will be rejected.

“WAN to LAN” parameter :

That parameter sets what the filter will decide if an IP packet coming from the WAN does not match any of the rules of the filter :

If the value “Accept” is selected, the IP packet will be transmitted to the LAN.

If the value “Drop” is selected, the IP packet will be rejected.

The cautious default policy is to choose the value “Drop”; at the opposite, if the value “Accept” is selected, a frame which does not match any of the rules of the filter is transmitted.

Step 2 : Add a rule to the filter

Click the “add a rule” button.

“Direction” parameter :

Select the direction of the data flow to which the rule applies.

“Action” parameter :

Select the value “Accept” if the IP packet has to be transmitted in the selected direction.

Select the value “Drop” if the IP packet has to be rejected.

“Protocol” parameter :

Select the level 3 protocol concerned.

“Source IP address” & “Source port” parameters :

Enter the value of the source IP address and the source port number.

It is possible to enter a range of source IP addresses and not a single IP address by selecting a netmask value from 1 to 32; It is the number of binary 1 of the netmask; for instance, the value 24 means 255.255.255.0; the value 16 means 255.255.0.0.

“Destination IP address” & “destination port” parameters :

Enter the value of the destination IP address and the destination port number. Select the netmask value.

20.3 Remote users filters

A remote user filter applies to the IP packets received inside a remote user connection.

25 remote user filters can be configured and assigned individually to each of the users declared in the user list.

A remote user filter is a table of destination port numbers and IP addresses belonging to the LAN network.

Once a remote user is connected to the RAS-3G router, the router applies the filter assigned to him (see the remote user form).

According to his identity (Login and password, he will thus only access to the IP domain defined by the filter.

Example :

Filter name : Access to the device PLC1 (html and modbus)		
Filter policy : All is forbidden except what we specify		
Rules list		
Action	Device	Service
Allow	PLC1 192.168.0.12	80
Allow	PLC1 192.168.0.12	Modbus 502

A filter must be assigned at least to one user to become enabled.


Step 1 : Complete, if necessary, the list of services

Remark : The main services (*html, ftp, modbus*) are available from factory; for that reason, most of the time, that step can be skipped.

- Select the menu “system” and then “service list” The list of TCP ports is displayed.
- Click « add a service ».
- Enter the label of that the new service, assign a protocol (udp, tcp, icmp) and a port number.
- Save. The list is updated.

Step 2 : Enter the list of devices of the LAN network

- Select the «System» menu, then «Devices list».
The list of the devices of the LAN network is displayed.



IPL-E-1220B Router Demo factory

Setup > System > Device list

Site name: Demo factory

Domain name:

Show web portal: ☒

This table allows to describe the devices (IP@ and device name) connected to the network; it will allow you :

- to build the firewall
- to automatically generate a web portal containing the devices names and IP addresses.
- to connect to the devices using their DNS name (DNS name = device name.Domain name).

Note : Describing a device in the table below is NOT a way to authorize access to it.
Once you will have described the devices, go to the Security menu to give or restrict access to one of them.


Device name	IP address		
Any	0/0	Modify	Delete
PLC12	192.168.1.12	Modify	Delete
PLC13	192.168.1.13	Modify	Delete
-	-		

Save Cancel Add a device


- Click « add a device ».
- Assign a label and an IP address to the device and click OK.

Step 3 : Build a remote user filter

- Select the « security» menu, then « firewall» and then «Filter list» The users filters list is displayed.



- Click « add a new filter ».



- Assign a name to the new filter.
- Choose the policy ; « All is forbidden except what we specify » is the advised policy.
- Click « add a new rule to the list ».
- Select a device among the ones which have been stored and a service (also called port).
- Add other rules if necessary.
- Click OK when the filter is complete ; the updated filter list is displayed.

Step 4 : Assign a filter to each user

- Select the « Remote user» and then « User list ».
- Select a user to which you want to assign a filter ; and click modify ; the user window is displayed.
- Assign a filter to the user ; click OK and save.

21 Serial to IP gateway

That function is available in RAS-3G-1220 or RAS-3G-1230

The RAS-3G features two serial asynchronous ports RS232 or RS485 (see the [product identification table](#)).

A serial gateway can be assigned to each port .

If the same type of gateway is assigned to both serial ports, the UDP or TCP port numbers must be different.

The gateways listed below are provided :

Modbus client or server (i.e. master or slave)

To connect several serial modbus slaves to several IP modbus clients.
Or to connect a serial modbus master to an IP modbus server.

RAW TCP server or client :

To connect 2 serial devices through an IP network.

RAW UDP :

To exchange serial data between several serial and IP devices, through an IP network, using a table of IP addresses.

Telnet :

To connect a Telnet terminal to the RAS.


Unitelway slave :

To connect a serial unitelway master to an IP network.

21.1 Modbus menu

21.1.1 Modbus server gateway

This gateway allows to connect asynchronous modbus slaves to the serial interface of the IPRS.



- Select the modbus menu and then modbus server and enable the modbus server gateway and set the parameters as follows :

“Port selection” parameter :

Select the serial port COM 1 or COM2.

If the modbus server gateway is assigned to one serial COM port, it cannot be assigned to the other one.

« ASCII / RTU protocol » parameter:

Select the right option

“Proxi” parameter:

Enable the proxi option if you wish to avoid to frequent requests on the RS232-RS485 interface.

“Cache refreshment period” parameter:

Select the period at which the gateway will send request to the slaves PLC.

“Timeout waiting for the answer” parameter:

Set up the timeout the gateway has to wait for the answer of the modbus slave answer.

“Local retry” parameter :

Set up the number of times the gateway will repeat a request before declaring a failure.

“Inter-character gap” parameter :

Set up the maximum delay the gateway will have to wait between a received character of a modbus answer frame and the following character of the same frame.

“Modbus slave address” parameter:

Choose “specified by the modbus TCP client” , if the address of the slave PLC must be decoded by the gateway from the modbus TCP frame coming from the client.

Otherwise, specify the modbus address of the slave PLC; in that case only one slave can be connected to the RS232 serial interface.

“TCP inactivity Timeout” parameter :

Set the time the gateway will wait before disconnecting the TCP link if no characters are detected.


“TCP port number” parameter :

Set the port number the gateway has to use.

If the Raw TCP client gateway is assigned to both serial COM ports, the TCP port numbers must be different on each port.

21.1.2 Modbus client gateway

This gateway allows to connect a serial modbus master to the serial interface of the IPRS.



- Select the modbus menu and then “modbus client” menu; enable the “modbus client” gateway and set up the parameters as follows :

“Port selection” parameter :

Select the serial port COM 1 or COM2.

If the modbus server gateway is assigned to one serial COM port, it cannot be assigned to the other one.

« ASCII / RTU protocol » parameter :

Select the right option

“Inter-character gap” parameter :

Set up the maximum delay the gateway will have to wait between a received character of a modbus answer frame and the following character of the same frame.

“TCP inactivity Timeout” parameter :

Set the time the gateway will wait before disconnecting the TCP link if no characters are detected.

“TCP port number” parameter :

Set the TCP port number the gateway has to use.

“IP address” parameter :

The modbus client gateway allows to transmit modbus requests from the serial modbus master device to any modbus slave device, more precisely called “ modbus server”, located on the IP network.

To assign an IP address to each modbus slave device with which the serial master device needs to communicate, click the “add a link” button; Assign an IP address in front of each modbus slave address with which the serial master device will have to communicate.

21.2 RAW TCP gateway

21.2.1 Raw client gateway

The RAW client gateway can be used if a serial “master” device has to send requests to one slave device (also called server) located on the IP network.

The server can be either an ETIC gateway or a PC including a software TCP server.



- Select the “transparent” and then the “raw client COM1” or the “raw client COM2” menu .
- Enable the raw client gateway; and set up the parameters as follows :

“RS232/485 input buffer size” parameter :

Set up the maximum length of an asynchronous string the gateway will store before transmitting it to the IP network.

“Timeout of RS232/485 end of frame” parameter :

Set up the delay the gateway will wait before declaring complete a string received from the asynchronous device.

Once declared complete, the gateway will transmit the string to the IP network.

“TCP inactivity Timeout” parameter :

Set the time the gateway will wait before disconnecting the TCP link if no characters are detected.

“TCP port number” parameter :

Set the port number the gateway has to use.

If the Raw TCP client gateway is assigned to both serial COM ports, the TCP port numbers must be different on each port.


“Raw server IP address” parameter :

The raw client gateway is able to communicate with a raw server gateway.

Assign an IP address to define the destination gateway.

21.2.2 Raw server gateway

That gateway can be used if a serial slave device has to answer requests coming from devices located on the IP network and acting like a master (also called TCP client).



- Select the “transparent” and then the “raw server COM1” or the “raw server COM2” menu.
- Enable the raw server gateway and set up the parameters as follows :

“RS232/485 input buffer size” parameter :

Set up the maximum length of an asynchronous string the gateway will store before transmitting it to the IP network.

“Timeout of RS232/485 end of frame” parameter :

Set up the delay the gateway will wait before declaring complete a string received from the asynchronous device.

Once declared complete, the gateway will transmit the string to the IP network.

“TCP inactivity Timeout” parameter :

Set up the time the gateway will wait before disconnecting the TCP link if no characters are detected.

“TCP port number” parameters :

Set up the port number the gateway has to use.

If the Raw TCP server gateway is assigned to both serial COM ports, the TCP port numbers must be different on each port.

21.3 RAW UDP gateway

21.3.1 Overview

The RAW UDP gateway enables you to connect together a group of serial or IP devices through an IP network.


The group can include IP devices if they have the software pieces able to receive or transmit serial data inside UDP.

Serial data transmitted by each device is transmitted to all other serial devices through the IP network.

A table of IP destination gateways is stored in each RAS-3G belonging to the group.

The serial data is encapsulated in the UDP protocol.

The UDP frame is sent to each destination IP address stored in the table.



21.3.2 Configuration

- Select the “gateway” menu and then the “Transparent” menu and then click “RAW UDP”.
- Select the “Activate” option.

« Serial input buffer size » parameter (value 1 to 1024) :

Sets the maximum size of an UDP frame.

“End of frame time-out” parameter (value 10 ms to 5 sec) :

Sets the delay the gateway will wait before sending the UDP frame towards the IP network when no characters are received from the serial interface.

«UDP port number» parameter :

Sets the UDP port number.

If the Raw UDP gateway is assigned to both serial COM ports, the UDP port numbers must be different on each port.

“IP addresses of the destination devices » table :

This table stores the IP addresses of the gateways to which the serial data, encapsulated inside UDP, have to be sent.

A different UDP port number can be entered for each destination IP address.

22 USB to IP gateway


22.1 Principles

The RAS-3G-1201 provides a USB to IP gateway.

It is able to forward IP traffic from devices connected to the Ethernet network to a USB device.

On the USB interface, the RAS-3G-1201 behaves like a USB host and a PPP client.

The USB device connected to the RAS-3G-1201 USB interface must behave like a PPP server.



Destination IP address; main case

When a device, connected to the Ethernet network, needs to transmit data to the USB device, the destination address of the IP frames which need to be transmitted to the USB device must be a specific IP address assigned to the USB gateway of the RAS-3G (see the configuration below).

Destination IP address; Modbus case

If no specific IP address is assigned to the USB gateway (see below), the RAS-3G forwards only modbus TCP traffic to the USB interface.

The destination IP address of the IP frames must be the LAN IP address of the RAS-3G router.

22.2 Configuration

Select the "Setup" menu and then the "USB" menu.

"Activate" checkbox :

Select the "Activate" checkbox.

"Use a specific IP address" checkbox :

If modbus TCP traffic only has to be forwarded to the USB device, that checkbox must not be selected.

If other kinds of traffic have to be forwarded, that checkbox has to be selected.

"Specific IP address" parameter :

If modbus TCP traffic only has to be forwarded to the USB interface, no IP address has to be entered.

If other kinds of traffic have to be forwarded to the USB device, an additional IP address must be assigned the RAS-3G.

That address belongs to the network connected to the LAN interface of the RAS-3G. It is the IP address of the USB gateway.

It will be used as the destination IP address of the IP frames which must be forwarded to the USB device.

"Accept WAN traffic" checkbox:

It is necessary to select that checkbox if the PC is connected to the network connected to the WAN interface.

It is not necessary to select that checkbox if the remote PC is connected to the RAS through a VPN.

23 Advanced functions

23.1 Adding a certificate

Coming from the factory, the RAS-3G router includes a certificate delivered by ETIC TELECOOMUNICATIONS acting as a certification authority.

That certificate can be used to set a VPN between two routers.

Two RAS-3G routers can set a VPN with one another using certificates only if the certificates have been provided by the same authority.

Additional X509 certificates, provided by ETIC Telecommunications or not, can be downloaded into the router.

To import a new certificate, the file extension can be PKCS#12 with a password or PEM.

Even if more than one certificate have been downloaded into the RAS-3G router, one certificate can be used for all the connections.

23.2 Alarms

23.2.1 SNMP

The RAS-3G router is able to send snmp traps when alarms occur.

Activation :

If that option is selected, the router will send an SNMP trap if an alarm is detected.

SNMP network management IP address :

Enter the IP address of the management platform

SysName & SysLocation :

That fields allow to identify the source device.

Example :

Sysname : etic

Syslocation : France

Product start-up :

If that option is selected, the router will send an SNMP trap each time it will connect to the Internet

23.2.2 Digital output alarm

If an alarm occurs, the router will open the digital output..

The causes which make the output to open can be either the ADSL disconnection, power input 1 failure, power input 2 failure.

23.2.3 E-mail alarm

When the digital input is closed or opened, an email can be transmitted to one of the users of the users list.

To set that function select the "Alarm" menu and click "email".

Enable the alarm email :

Select this option if you want an email to be sent to a user when the digital input 1 is set ON or OFF.

Alarm launched on event :

If the option OPEN is selected, the alarm will be sent each time the digital input will be opened.
If the option CLOSED is selected, the alarm will be sent each time the digital input will be opened.
If the option BOTH is selected, the alarm will be sent each time the digital input will be opened or closed.

Hold time :

Select the time the input has to stay in its alarm state to be taken into account.

Alarm destination :

Select the user to whom the email must be sent.

Text to send :

Enter the email text.

23.3 Configuring the web portal


The web portal in an html page; it displays a list of devices connected to the LAN. Each line of the list is made of the device name, its IP address and three links :

The html link : To go directly to the web server of the associated machine.

The « explore » link : To explore the HD of the associated machine, if it is a Windows machine.

The « ftp » link : To explore the files of the associated device.

If the we portal option has been selected (see below), the web portal page is displayed when the remote user launches the navigator and enters the Ip address assigned to the RAS-3G router. In that case, the administration server, usually can be displayed at the same address but at the port number 8080 instead of 80 when the web portal page option is not selected.



23.4 Configuring the DNS server

For domain names resolution, the RAS-3G can behave like a domain name server or a domain name relay.

DNS server :

A domain name server is a networking device which is able to associate a label (etictelecom.com for instance) with an IP address.

That function allows a client device to send a request to a network equipment referring to a domain name as if it was the actual IP address of the destination device.

The RAS-3G router is able to resolve any domain name composed with the name of one of the devices entered in the devices list followed the site name which is entered at the top of the devices list.

DNS relay :

The RAS-3G router behaves also like a DNS relay; any DNS request it receives from the LAN, which cannot be resolved because the device is not registered in the devices list, will be transferred to the internet to be resolved.

That function can be carried out only if the RAS-3G IP address is pointed out as the main DNS server of the devices of the LAN.

That function is efficient in particular when a device connected to the LAN has to send emails through the Internet.

1 Diagnostic menu

The html server provides extended diagnostic functions.

Select the Diagnostic menu and then the appropriate sub-menu.

- **Log sub-menu:**

The log displays the last 300 dated events :

3G, VPN and users connections and disconnections,
power on,
Serial gateway events.

- **Network status sub-menu and then status sub-menu :**

That screen displays the current status of the LAN interfaces and of the WAN (3G) connection :

LAN interfaces :

That part of the page shows the data of the LAN interface :

MAC address,
Ethernet mode (10 /100, half or full),
IP address.

WAN interface (3G-GPRS-EDGE) :

3G signal strength :

It must be better than – 90 dBm to en

Remark : As the number is negative, -85 dBm is better than –90 dBm for instance.

State : Connected or not to the 3G network

Local IP address :

It is the IP address assigned by the provider to the « antenna » (WA interface) over the 3G network.

In other words, it is the PPP client IP address.

Remote IP address :

It is the IP address of the PPP server belonging to the 3G network.

- **VPN sub-menu**

That menu displays the table of the VPN (remote user connections and remote routers connections) which are established.

- **Serial gateway :**

That page displays the current status of the serial gateways :

- Type of the gateway (Modbus, RAW, Telnet ...),
- serial port set-up (data rate etc...),
- number of characters received or sent,
- Number of TCP frames or UDP datagrams received or sent,
- Number of TCP connections enabled.

The View link displays a window which shows the hexadecimal received and transmitted traffic over each serial COM port.
It can be a great help for trouble shooting.

2 Saving the configuration to a file

Once a product has been configured, the parameters file can be stored and restored when necessary.

To save the parameters into a file,

Select the "System" menu and then "Save restore",

Click the "Save" button

Select the location to store the configuration and give a name to the file.

The file suffix is ".bin".

To restore a parameters file

Select the "System" menu and then "Save restore",

Click the "browse" button and select the parameters file,

Click the "Load" button and confirm to restart the product.

Attention :

A parameters file can only be downloaded to a product having the same firmware version.

It is why, we advise to assign a name to a parameter file including the product name and the software version.

Example :

Name of a parameters file for an RAS-3G-1220 router with the firmware version V2.4 :

Myrouterfile_ras3g1220_V241.bin

3 Updating the firmware

Step 1 : Before starting, you need,

A PC with a Web browser.

An Ethernet cable or a switch

The FTP server software which can be downloaded from the « firmware page » of the ETIC « download area » web server.

Step 2 : Download the release of the firmware from our download area to your PC**Step 3 : Prepare the PC**

Check the Ip address of the PC is compatible with the one of the router.

Connect the router to the PC.

Launch the TFTP server (tftp32.exe) software and select the new release (L026xxx/img) by using the "Browser" button.

Click on "Show dir" to check the files of the directory : rfsmini.tgz, rootfs.bin, u-boot.bin and ulmage.

Step 4 : Update the firmware

Launch the web browser

Enter the IP address of the ETIC product ; the home page of the ETIC configuration server is displayed.

Select the "System" menu and then " firmware Update". In the field "IP address of the TFTP server", enter the IP address of your PC.

Note : The IP address of the PC is written in the field "Server Interface" in the TFTP server windows.

Click "Save" and then "Update".

The first file should begin to be downloaded from the PC to the router.

During the operation, the led blinks

When the download is finished, the product automatically reboots.

Check the new release has been installed, go to "About" in the administration web page of the IP product.

1/ Setup menu

Remote users	To assign an ID and PWD to each authorized user and set their rights To set the M2Me service
LAN interface	To enter the IP @ of the router on the LAN interface. To enter the IP @ assigned to the remote users To set up the Ethernet interfaces To set up the DHCP server on the LAN interface
WAN interface	To enter the IP @ of the router over the WAN interface.
Network	To configures the VPNs To enter static routes and enable the RIP protocol To set up the VRRP redundancy protocol To set up port forwarding To set up advanced Ip addr. translation functions
Security	To set the firewall rules (User filter and main filter) To add a certificate To restrict access to the administration server
Alarm	To set up alarm SNMP traps To set up alarm emails
Serial gateway	To set up the modbus gateway (client / server) To set up the Unitelway gateway To set up the RAW TCP / RAW UDP / TELNET gateways
System	To set up SNMP parameters To enter the devices list To update the service list To update time and date

2/ Diagnostic menu

Log	To display the events (VPN connections, user connections..)
Network status	Interfaces status : @ MAC, @IP, ADSL, VPN VPN status Routing tables M2Me_Connect status
Serial gateways	To display the status of each gateway (COM1 and COM2)
Tools	To send Pings from the router
Hardware	To display the input status To control the output To display the DIP switches status
Environment	To display the internal T° and the supply voltage
Advanced	To store the internal report to a disk for diagnostic purposes

3/ Maintenance menu

Firmware update	To update the firmware
Save / restore	To save or restore a configuration file To restore the factory configuration
Reboot	To restart the router

4/ About menu

To display the certificate "product key"
To display the firmware version



13, Chemin du Vieux Chêne

38240 Meylan - France

Tel : 33 4 76 04 20 00

Fax : 33 4 76 04 20 01

E-mail : contact@etictelcom.com

Web : www.etictelcom.com